

PROGRAMMING MODE MENU

To enter the programming mode hold ENTER and ESC buttons for 5 seconds

HIGH LEVEL ALARM	H.A	TRIP POINT	tr iP		
		RELEASE POINT	rELS		
		AUDIO ALARM	bEEP	ON	On
				OFF	OFF
LOW LEVEL ALARM	Lo A	TRIP POINT	tr iP		
		RELEASE POINT	rELS		
		AUDIO ALARM	bEEP	ON	On
				OFF	OFF
RELAY ONE	rEL 1	TRIP POINT	tr iP		
		RELEASE POINT	rELS		
		POLARITY	POLr	NORMALLY OPEN	no
				NORMALLY CLOSED	nc
RELAY TWO	rEL 2	TRIP POINT	tr iP		
		RELEASE POINT	rELS		
		POLARITY	POLr	NORMALLY OPEN	no
				NORMALLY CLOSED	nc
RELAY THREE	rEL 3	TRIP POINT	tr iP		
		RELEASE POINT	rELS		
		POLARITY	POLr	NORMALLY OPEN	no
				NORMALLY CLOSED	nc
RELAY FOUR	rEL 4	TRIP POINT	tr iP		
		RELEASE POINT	rELS		
		POLARITY	POLr	NORMALLY OPEN	no
				NORMALLY CLOSED	nc
DISPLAY BRIGHTNESS	br it	LEVELS 1 - 4	br - 4		
SENSOR LENGTH	LEn	TOP SENSOR	toP		
		BOTTOM SENSOR	bot		
DISPLAY UNITS	Un it	FEET (decimals)	FEET		
		% OF SENSOR	PERc		
		METERS	SI		
		VOLUME	CubE	(future)	
SOFTWARE VERSION	Code	(displays installed version)	303		
REPROGRAM AND RETURN	Quit				

MODEL 200C

Press UP or DOWN to scroll up and down through the columns of the menu
 Press ENTER to move to the right on the menu
 Press ESC to move to the left on the above menu
 Press UP or DOWN to increase or decrease a numeric value
 Press ENTER to temporary store **Stor** changes made to a value
 Scroll to QUIT and press ENTER to exit programming mode and to reprogram any temporary changes